



G-Max Feed Wagon

Operation & Parts Manual



Disclaimer

While every attempt has been made to ensure that information and diagrams in this manual are correct, Giltrap Engineering Limited will not be responsible for any damage or consequential loss arising out of misinterpretation or failure to follow recommended procedures; nor will it be liable for any damage caused by or arising out of modification or misuse of its product.

For parts or service enquiries, please use the applicable contacts on the previous page.

Printed June 2026

Copyright © 2026 by Giltrap Engineering Ltd.
Printed in New Zealand

All rights reserved. Reproduction or use, without express permission, of editorial or pictorial content, in any manner, is prohibited.

Table of Contents

Introduction	5
MANUAL EVALUATION	5
Warranty	6
Serial Number Identification.....	7
General Safety.....	8
Pre-Service Guidelines & Settings.....	11
Installation	13
ELECTRIC CONTROL INSTALLATION (WHERE EQUIPPED).....	13
IN-CAB TOUCHSCREEN MONITOR CONNECTIONS	13
TRACTOR LOOM CONNECTIONS	14
HEAVY DUTY CROSS CONVEYOR EXTENSION HYDRAULIC CONNECTION	15
Operation	16
LOADING THE WAGON	16
FEEDING OUT	16
MANUAL CONTROL OPERATION	16
ELECTRONIC CONTROL OPERATION.....	19
WIRELESS SCALES	21
WIRELESS SCALES WITH PHONE/DEVICE SCALES DISPLAY	23
CONNECTING YOUR DEVICE TO WAGON SCALES WIFI.....	24
CROSS CONVEYOR POSITION ADJUSTMENT	25
SIDE SHIFT OPERATION	26
HYDRAULIC JACK OPERATION	26
REAR GATE OPERATION	27
Maintenance	28
FLOOR CHAIN TENSION	28
ELEVATOR CHAIN TENSION	28
CROSS CONVEYOR BELT TRACKING.....	29
REAR GATE CRASH LOCK ADJUSTMENT.....	30
LOAD CELL MAINTENANCE	31
Greasing and Lubrication.....	32
Technical - Electronic Control System	35
DISTANCE MODE – ADJUSTING PARAMETERS	35
SCALES ONLY DISPLAY - WEIGHT READOUT DAMPING	36
STANDBY TIME ADJUSTMENT	38
UPDATING SOFTWARE VERSION	39
EXPORTING SETTINGS TO USB	40
IMPORTING SETTINGS FROM USB.....	41
TROUBLESHOOT - ENCLOSURE CIRCUIT BOARDS IDENTIFICATION	42
TROUBLESHOOT - LED STATUS LIGHTS	43
TROUBLESHOOT - DIAGNOSTIC NOTES.....	46
TROUBLESHOOT – SYMPTOM TABLE	48
TROUBLESHOOT - LOOM PLUG WIRING	49

Technical - Hydraulic System Troubleshoot	50
4045A VALVE LAYOUT – ELECTRONIC CONTROL	51
4045A VALVE LAYOUT – MANUAL CONTROL	52
Parts Section	55
ELECTRONIC CONTROL SYSTEM COMPONENTS	56
BOTTOM CHASSIS	58
RIMA JACK.....	59
FRONT PANELS – JUNE 2025 ON.....	60
FRONT PANELS – PRE- JUNE 2025 – BOLT-ON COMBING RAIL	62
FLOOR CHAIN DRIVE ASSEMBLY – JUNE 2025 ON.....	64
FLOOR CHAIN DRIVE ASSEMBLY – PRE-JUNE 2025	65
FLOOR CHAIN IDLER ASSEMBLY	66
FLOOR BAR SETUP	67
BELT CROSS CONVEYOR	68
CHAIN CROSS CONVEYOR	69
HEAVY DUTY CROSS CONVEYOR EXTENSION – CONVEYOR.....	70
HEAVY DUTY CROSS CONVEYOR EXTENSION – MOUNTS	71
ELEVATOR – JUNE 2025 ON.....	72
ELEVATOR – TOP ASSEMBLY – PRE-JUNE 2025.....	74
REAR GATE	75
CONTROL ENCLOSURE COMPONENTS.....	76
MUDGUARDS	77
AXLE ASSEMBLY	78
HUB ASSEMBLY – ADR	79

Introduction

Thank you for purchasing a Giltrap product. *Giltrap Engineering Ltd* has enjoyed a long-standing success with their machinery. We would like you to enjoy the benefits of owning a Giltrap too. By following the guidelines laid out in this book, you will ensure trouble free, low maintenance operating for years.

Giltrap Engineering Ltd is a progressive company which continually strives to satisfy your needs, so we welcome any feedback which you can provide to help us improve our products and services and to ensure that they perform to your expectations. Any constructive comments about this operator's manual are also welcome.

Your machine has been designed to perform its task efficiently and with a minimum of maintenance. This handbook provides safety guidelines, instructions, maintenance requirements and parts listings. We recommend that you read the entire handbook, before operating the machine as this will enable you to take full advantage of your new machine's considerable potential.

Manual Evaluation

We update our operating manuals regularly. Your suggestions for improvement help us to create even more user friendly manuals. Send your suggestions by email to admin@giltrapag.co.nz.

Delivery and Warranty

Before you begin to use your machine, please check it to make sure there is no delivery damage. If damage is evident, contact the dealer who supplied the machine so that they can make the appropriate claims.

If you have any other queries, please contact your dealer or *Giltrap Engineering Ltd* (0800 80 GILTRAP).

All Giltrap products are covered by a 24-month warranty on parts and labour, subject to normal use.

Please fill in the details below for future reference.

Model:

Serial No:

Delivery Date:

Dealer:

Warranty

The Goods specified in the Price List as designed and supplied by Giltrap Engineering Ltd are warranted against faulty workmanship and defective materials for a period of 24 months from the date of purchase. In addition to the primary 24 month warranty for Giltrap products, there is a further 12 month structural warranty for the goods, against faulty workmanship and/or defective materials for structural items only. The structural warranty does not apply to electronics or component parts.

Such warranty is subject to the following conditions:

1. This warranty covers the repair or replacement of parts or machinery sold by the manufacturer and damaged as a result of the faulty workmanship or materials in such parts or machinery. It does not extend to any other loss or damage including consequential loss or damage or loss to other property or persons.
2. Without limiting the generality of paragraph 1 above, this warranty does not cover the following:
 - (a) Travel expenses.
 - (b) Damaged caused by accident, misuse or abuse.
 - (c) Damage to any goods which have been altered or modified by someone other than the manufacturer or its authorised agent.
 - (d) Damage or loss to the goods due to their unsuitability for any particular use or for using with any particular tractor except where such use or tractor had been specifically approved by the manufacturer.
 - (e) Damage or loss where the fitting and installation of the goods were not carried out by the manufacturer or its authorised dealer.

3. Procedure for recovery under warranty.

No loss or damage will be covered by this warranty unless the loss or damage is reported immediately to the dealer (who will contact the distributor who will advise whether it is covered by the warranty and undertake the necessary action).

No warranty repair work is to be undertaken prior to an order number being obtained.

This warranty shall be interpreted according to the laws of New Zealand and the parties agree to submit to the jurisdiction of the Courts of New Zealand.

Warranty Claims

If you wish to make a claim under warranty:

- Immediately stop using the machine.
- List details of the machine and damaged item including serial numbers and date of purchase.
- Consult with your Giltrap dealer (supplier) and have him forward your claim and the damaged item to Giltrap Engineering Ltd.

No warranty to be undertaken unless an order number is obtained from the Seller (Giltrap Engineering Ltd) prior to any work being done.

Serial Number Identification

Before ordering any parts, check the serial number and the delivery date of the machine and include this information with all orders.

If the Serial Number Plate is missing, the serial number will be stamped on the front of the drawbar.



Tel +64 7 873 4199
www.giltrapag.co.nz
7 Main North Road
Otorohanga
New Zealand

DRAWBAR VERTICAL RATING (kg):

GROSS LADEN MASS (kg):

SERIAL No:

MODEL No:

This plate is provided in compliance with the NZ Land Transport Heavy Vehicles 2004 rule, section 4.2. It is the operator's responsibility to ensure that this unit is fully compliant with all current legislation when it is used on public roads. **Removal of this plate invalidates certificate.**

Serial number stamped
onto chassis here




General Safety

For the safety of others and yourself, please read and follow the precautions in this operator's manual. Pay particular attention to the following safety aspects of operating machinery.


Do not ride on or allow passengers on the machine.




Always use a recognised hitch pin with a safety clip to hook trailed implements on behind the tractor.



Always ensure when using a quick hitch that the locking tab has come out and is in the locked position before moving.



When pulling trailed implements or loads, be sure to use a tractor of greater or equal weight than the combined weight of the load and trailer.



Carry a suitable fire extinguisher.

A fire can ignite under certain conditions, so please take the following precautions:

After running your machine for a short time, check for defective bearings. A faulty bearing can become very hot, eventually discolouring, requiring immediate replacement.

Do not allow combustible material to accumulate inside guards or around rollers and other moving parts.

If your machine becomes blocked, stop immediately and remove the obstruction.


Be careful when operating in hot or dry conditions or on extreme fire risk days.



Never operate your machine without the safety guards in place.



All chains should be properly adjusted and replaced when necessary.



Release all hydraulic pressure from implements before commencing service work. Never look for suspected oil leaks with your hands or body - use a piece of cardboard instead. Any fluid that penetrates the skin will have to be removed immediately by a medical expert. Seek specialist advice on this type of injury.



Never attempt to unblock equipment while it is still operating. Always disengage power take-off, hydraulics and shut down engine before removing materials, checking or servicing. Failure to follow these precautions is likely to result in serious injury.



Wear proper protective clothing. Loose attire can easily be snagged by rotating machinery resulting in serious injury or death.




Pre-Service Guidelines & Settings


Prior to delivering your machine, your dealer should have completed a pre-delivery check.

It is beneficial to check the following points before using the machine for the first time, after the first few loads, then weekly.

CHECK FLOOR CHAIN TENSION. A simple check is to stand in the bin and exert a strong pull at the centre of the floor. There should be approximately **75mm (3")** of vertical movement in this area.



CHECK ELEVATOR CHAIN TENSION. Exert a pull at the mid-point of the elevator face. If necessary, adjust for approximately **35mm (1-1/2")** of movement from rest towards the rear of the wagon.



- CHECK ALL WHEEL NUTS ARE SUFFICIENTLY TIGHT.

Wheel Nut Recommended Torque Settings

M18 Stud	200 ft/lbs or 270Nm
M20 Stud	280 ft/lbs or 380Nm
M22 Stud	330 ft/lbs or 450Nm



- CHECK ALL TYRE PRESSURES ARE CORRECT.

Recommended Tyre Pressures

11.5/80-15.3	58psi	4.0 bar
400/60-15.5	50psi	3.5 bar
15.0/70-18	45psi	3.1 bar
400/55-22.5	46psi	3.2 bar
500/45-22.5	35psi	2.4 bar
500/60-22.5	35psi	2.4 bar
560/45R22.5	58psi	4.0 bar
560/60R22.5	58psi	4.0 bar
650/55R26.5	58psi	4.0 bar



- CHECK ALL AXLE MOUNTING BOLTS AND NUTS ARE SUFFICIENTLY TIGHT.

Axle Mounting Bolt Recommended Torque Settings

M16	180 ft/lbs or 245Nm
M20	355 ft/lbs or 480Nm

- THE SIDE CONVEYOR BELT should be checked for alignment and tension, and adjusted if necessary to ensure it is tracking correctly.
- THERE ARE SEVERAL GREASE POINTS on all Giltrap feeders. Check the yellow label on the side of your machine to see how many grease points there are. You should fully grease everything before running it for the first time. See greasing and lubrication section in manual.
- CHECK AND RETIGHTEN WHEEL NUTS AFTER:
 - First use
 - First laden journey
 - The first 50 hours of use and every 50 hours thereafter

Installation

IMPORTANT: GREASE Elevator and Floor bearings and pins Daily for the first week. This allows the porous cast bearings and sprockets to absorb the grease. Then refer to table in the Lubrication section. Always grease & oil the machine after it has been in storage or unused for a long period of time.

Connect drawbar to tractor. The hydraulic jack (where fitted) may be used as a quick hitch foot.


Retract hydraulic jack or wind-up jack handle and stow jack

Connect hydraulic hoses
Connect brake hose (if equipped)
Connect lights plug
Connect Electric control system plug (if equipped)

Set Hydraulic flow to 30-60lpm at full working pressure: 2500 - 2800psi.


Electric Control Installation (where equipped)

Fit monitor in cab. Power supply should be connected directly to tractor battery. It is recommended to fix the connection socket to the tractor – this will allow auto release mechanism to work.




Use supplied plate to mount loom plug to tractor. Modify and bolt in place as necessary.

In-Cab Touchscreen Monitor Connections



Tractor loom Connections




Connect Wagon loom plug to Tractor loom socket.

Note: Wagons fitted with Phone/Device Scales display use a different Tractor loom – see ‘Wireless Scales with Phone/Device Scales Display’ section.

DO NOT TOGGLE ON / OFF SWITCH IN QUICK SUCCESSION

Heavy Duty Cross Conveyor Extension Hydraulic Connection

1. Remove hose from BOTTOM port on cross conveyor motor
2. Connect hose between TOP port on the extension motor and BOTTOM port on cross conveyor motor
3. Connect hose between BOTTOM port on extension motor and hose that was disconnected from the BOTTOM port on the cross conveyor motor.



Operation

Loading the Wagon


Load the wagon from the rear to the front. When difficult material has to be handled, eg long, wet silage, load the material in sections. It may sometimes be necessary to reverse the load a short distance and then bring it forward again to present a new face to the elevator. Note: reverse the floor by pushing the hydraulic lever on your tractor in the opposite direction.

Feeding Out


Best feeding out conditions occur when the wagon is freshly loaded. If left loaded overnight, the material can settle into a hard mass that becomes difficult to feed out. The practice of leaving a load in the machine for hours before feeding out will also accelerate the deterioration of the wagon because of the acidic nature of the material.

Manual Control Operation

Where electronic control is not fitted, feeding is controlled by manual adjustment of the hydraulic valve block. The hydraulic block is located under the stainless steel cover on the left side of the wagon. The two adjustments for the block may be accessed through the cut out in the back plate.



Adjustment Knobs (Manual control):



Conveyor Belt Speed Control

Belt speed is adjusted using the red knob shown. The conveyor belt takes priority oil flow.

Turning the valve clockwise increases the conveyor belt speed.

Feed-Out Rate Control

Feed Out rate is adjusted using the black knob shown. This adjusts the load pressure that the valve uses to start and stop the floor automatically. When you have adjusted the feed-out rate to your requirements, the valve will maintain an even flow of material to the elevator by automatically adjusting the floor speed. As the wagon empties the floor will automatically speed up to its maximum speed.

Turning the valve clockwise increases the feed out rate.


If the elevator chain stalls from overloading, reduce this setting.

To Feed Out, engage tractor hydraulics and drive forward. Ensure hydraulic flow is sufficient to cause the elevator to turn smoothly (30-60 litres per minute at full working pressure: 2500 - 2800psi (170 – 190 bar)).

Manual Hydraulic Control (Override) of Electronic system

The Electronic Control system (when fitted) sends power to two electric coils on the hydraulic valve block. To use the machine in manual mode, both of these controls must be manually over-ridden.

The hydraulic valve block is located on the left-hand side of the wagon, at rear of the stainless-steel covered enclosure.



- The Red knob controls conveyor belt speed.

Elevator - The elevator control black knob is a 'locked-unlocked' type.

- When set for Electronic control, the knob will 'spring to centre' if turned slightly either way. In this position the Elevator is electrically turned on and off as Run/hold is pressed.

- For Manual operation, turn the knob anti-clockwise until it 'clicks' & holds its' position. The Elevator is now locked 'On' and will run whenever the hydraulics are engaged.


Floor –The Floor control black knob is a rotary adjustment type.

- When set for Electronic control, this knob is turned all the way out (anti-clockwise).


- For Manual operation, turn this knob clockwise until the floor moves when the hydraulics are engaged. This overrides the electric control of feed rate. The feed rate may then be adjusted by screwing the knob in (higher rate) or out (lower rate).

Turn on the in-cab touchscreen monitor using the switch on the Tractor loom. Engage the tractor hydraulics. The Cross conveyor belt will run continuously. Cross conveyor belt speed is adjusted as per manual adjustments above

On wagons equipped with electronic rate control, the feed rate may be adjusted from the tractor cab. Once hydraulics are engaged, feeding out is also turned on and off using the touchscreen.




With Scales fitted, the weight of product in the wagon and the amount dispensed are displayed.



Weight Mode


With Scales fitted, Weight mode allows a pre-set amount of feed to be dispensed before the wagon automatically stops feeding



Rate Control with Scales and Wheel Speed Sensor Fitted

Distance Mode


With Scales and a Wheel speed sensor fitted, Distance mode allows a pre-set amount of feed to be dispensed over a pre-set distance before the wagon automatically stops feeding. This is useful when feeding into troughs or to ensure a sufficiently long feed-row in a paddock.



For fine tuning adjustment see 'Technical' section.

Wireless Scales

When equipped with Load cells, the bin weight may be monitored in real time, even with the wagon disconnected from the tractor. The system uses its own built-in WiFi to communicate.



Note: when disconnected from the tractor, the system:

- cannot operate feeding controls
- cannot set bin weight to zero

Both these tasks require the electrical plug and socket to be connected. The 'Wagon Active' and green socket symbol will be displayed when the wagon is plugged in to the in-cab monitor:



When the electrical plug and socket are disconnected, the Wifi will become active for displaying weight:



The wagon may now be loaded by the towing tractor, with live bin weight readout in the cab.

NOTE: If the tractor goes out of range of the Wifi, or if the wagon control box times out and turns off, the Wifi symbol will turn Red, indicated a broken connection. To reconnect, either move the tractor closer to the wagon, or press the Standby Button on the control box.


For Weight readout damping adjustment see 'Technical' section.

Wagon Standby Button

When the electrical plug and socket to the tractor are disconnected, the wagon control box remains on for a set length of time to allow for wireless scales display. Once time is up, the control box will turn off to conserve on-board battery power.

To turn the unit back on, either plug in the tractor electrical plug and socket, or press the 'Standby' button located above the hydraulic valve controls.


For Standby time adjustment see 'Technical' section.



DISCONNECT OR ISOLATE WAGON BATTERY IF PARKING UP FOR MORE THAN TWO WEEKS.

Wireless Scales with Phone/Device Scales Display

Wagons fitted with this option use the simplified Tractor loom below:



The wireless scales need to be connected to the tractor regularly to keep the on-board battery charged. The Switch needs to be turned On for charging to occur.

Most Devices capable of receiving WiFi can be used as a readout for the Wagon scales.

The Control System on the wagon needs to be turned On in order for scales to work. Either connect the tractor cable, or press the 'Standby' button on the wagon.

The QR Code giving access to the WiFi signal is displayed on the outside of the Control System enclosure under the stainless steel cover on the left side of the wagon. Follow the steps below to connect.

Connecting your Device to Wagon Scales WiFi

First Connect to the Wagons' WiFi signal

- 1) On your device ensure your WiFi is enabled.
- 2) Ensure both WiFi Calling and mobile data is off. (This may not be necessary in some devices).
- 3) Select WiFi signal: Connect to LC-(ID code). Enter Password: **FarmscanAG**
For machines built prior to June 2026, Password is: **12345678**
Disregard any warning you are connected BUT have no internet – this is normal.




Then Navigate to the Scales webpage


- 4) Open your QR code reader. This may be built into the camera. Scan the QR code sticker on the Wagon and it will bring up a URL of **192.168.17.1**
For machines built prior to June 2026, URL is: **192.168.4.1**
- 5) For Android, select preferred web browser.
- 6) Some devices will search for the Google site. If so, open a new browser tab. In the address bar type in the relevant URL from above.
- 7) The Scales display web page will load:
- 8) Tapping Tare or Gross will change the weight display. Note this will affect all connected devices.
- 9) A shortcut to the display page may be added to the Devices Home screen for easy future connection. To add the shortcut:

iPhone: Tap  then Add to Home Screen 

Android: Tap  then  Add to home screen then 



Cross Conveyor Position Adjustment



An important feature of the G-MAX series wagons is the ability to adjust the position of the cross conveyor assembly relative to the chassis. The cross-conveyor unit may be set to one of three positions, each giving different extension out the side.

It may be necessary to loosen the 2 clamps at the front of the machine.

Remove the retaining clip, withdraw the locating pin, slide the unit manually to suit, locate the pin in a hole, and re-fit the retaining clip underneath the locating pin.

If the optional 'side-shift' ram is fitted, bed movement can be done from the tractor seat via hydraulics.

Side Shift Operation

The side shift hydraulic ram is located underneath the cross conveyor. Actuating it out allows 300mm of sideways extension to feed into troughs, along fence lines, etc.




To operate, connect the two side shift hydraulic hoses to the tractor and adjust cross conveyor position using the tractor hydraulics.

Ensure cross conveyor bed is retracted before driving through narrow areas such as gateways, to avoid potential damage.

Hydraulic Jack Operation

The hydraulic jack (when fitted) is located underneath the front of the drawbar. In its' folded up position it may be used as a Quick Hitch foot. The height may be adjusted to provide most convenient tow eye height.




To operate, connect the two jack hydraulic hoses to the tractor. Standing away from the drawbar (in case of movement), turn the on/off lever to point along the hose (On position). The jack height may now be adjusted using the tractor hydraulics.

When disconnecting the wagon, set the jack height as necessary and turn the on/off lever to 'Off' before disconnecting hoses.

Upon initial installation, air may be present in the hydraulic jack ram. This may be purged by cycling the jack from fully up to fully down a number of times.

Rear Gate Operation

The rear gate may be manually un-latched by pulling rearwards on the handle:



A stay is fitted which locates in the gate to hold it open for access.

Note the gate will automatically open when the main floor is reversed and product pushes against the gate. Afterwards the gate must be manually re-latched.


To re-latch the gate, hold the handle down while pushing the gate firmly against the back of the wagon. Then push the handle upwards until it engages through the ball catch.

DO NOT ENTER WHEN WAGON IS IN OPERATION. IT IS RECOMMENDED THE TRACTOR IS SWITCHED OFF AND KEYS REMOVED BEFORE ENTERING THE WAGON

Maintenance


Floor Chain tension

Adjust floor chain tension as per pre-service guidelines on page 10. The adjusters are located at the rear of the machine near the sprockets. Undo the locknut (where fitted) before making adjustment. Adjust both sides approximately evenly.



Elevator Chain tension


Adjust elevator chain tension as per pre-service guidelines on page 10. The adjusters are located under the upper elevator sprockets. Undo the locknut (where fitted) before making adjustment. Adjust both sides approximately evenly.



Cross Conveyor Belt tracking

The side delivery belt is set up and adjusted at the factory before delivery; however it is usual after a period of time to notice the belt running off centre. This is normal and is caused by belt stretch or movement under load.

The adjusters are located on the left hand end of the cross conveyor unit. First, loosen the lock nut each side. Turn the bolt heads $\frac{1}{4}$ turn at a time with the conveyor running, until the belt runs true again. You should either loosen one adjuster slightly, or tighten the other, or a combination of both. Tighten lock nuts once adjusted.



All adjustments must be made with wagon running, preferably empty. Only adjust $\frac{1}{4}$ of a turn at a time and run for at least 2 minutes between adjustments. THE BELT WILL RUN TO THE LOOSE SIDE.

DO NOT OVERTIGHTEN - THIS WILL CAUSE A POWER LOSS!

Rear Gate Crash Lock Adjustment




The load setting of the crash lock system can be adjusted by removing the end cap fitting which encloses a compression spring that applies pressure to the ball bearing that locks the handle in place. The adjustment is made via a threaded adjuster within the spring assembly. Replace the end cap after adjusting.

Load Cell Maintenance

Clean mud and material buildup off all Load cells regularly as necessary.

1. Back off this top Nylock nut.
2. Lubricate Spherical washer with CRC or WD40
3. Tighten this Nylock nut to 200Nm



Check wire is not broken, squashed or damaged.


Greasing and Lubrication


GREASE Daily for the first week, then as per the table below. Always grease and oil the machine after it has been in storage or not used for a long period of time.


Grease Grade Recommended: NLGI 2 oil based
Gearbox Oil Recommended: GL-5 80w-90

Schedule		
Item		Frequency
Axle Bushes	(axle grease blocks)	– Grease every second day
Elevator Drive Shaft Bearings	(on forward grease block)	– Grease every 10 loads
Floor Driveshaft Deadeyes	(on forward grease block)	– Grease every 10 loads
Elevator Idler Sprockets		– Grease every 10 loads
Floor Idler Sprockets		– Grease every 10 loads
Cross Conveyor Drive End Bearings		– Grease monthly
Tow Eye		– Grease monthly
Jack Stand		– Grease monthly
Wheel Hubs		– Grease every 3 months
Rear Gate Latch		– Grease every 3 months
Elevator Gearbox		– Maintain level as necessary
Floor Drive Gearbox		– Maintain level as necessary

See diagrams next two pages








Technical - Electronic Control System

In addition to normal operation, the electronic control system features user accessible background settings, to further enhance the machines capabilities.

Distance Mode – Adjusting Parameters


If it is found that the machine regularly over-feeds a certain weight while in Distance Mode, adjust the Early Finish Weight parameter to this weight. The machine will stop running earlier to allow for this extra output, thus increasing accuracy.




1. Tap Spanners




2. Tap Double Cog




3. Tap Machine



4. Tap Control




5. Tap 'Early Finish Weight'




6. Enter the Weight value and tick out

If it is found that the machine regularly continues feeding past the end of the set Distance (while in Distance Mode), adjust the Early Finish Distance parameter to this distance. The machine will stop running earlier to allow for this extra length of feed, thus increasing accuracy.

Follow Steps 1-4 above then:




5. Tap 'Early Finish Distance'



6. Enter the Distance value and tick out

Scales Only Display - Weight Readout Damping


If the G-MAX wagon is optioned with In-cab monitor with Scales Display only, the Weight readout value may fluctuate when moving over rough ground. To adjust the readout damping:




1. Tap Spanners



2. Tap Double Cog



3. Tap 'Bin 1'



4. Tap 'Load Cell Configuration'

Bin 1 Machine Display

of Load Cells 6

Calibrate

Individual Cell Measurements

Current Bin Level 0.0 kg

Zero Bin weight

Red X Green Checkmark

5. Scroll down

Bin 1 Machine Display

Zero Bin weight

Weight smoothing period 5

Round to zero 15 kg

Smooth weight while stopped

Red X Green Checkmark

6. Tick 'Smooth weight while stopped'

- The Scales Only option has no ground speed sensor, so the control system is always considered to be 'stopped'

Bin 1 Machine Display

Zero Bin weight

Weight smoothing period 5

Round to zero 15 kg

Smooth weight while stopped

Red X Green Checkmark


7. Adjust the 'Weight smoothing period' value

- The higher the value, the smoother the readout will be, however it will give slower response to change in weight.


Standby Time Adjustment

When the Wagon is disconnected from the towing tractor, the scales system will remain On for a set time, to allow weight reading from WiFi connected devices. Once the set time is passed, the system will turn Off to conserve battery power. To adjust the Standby time, follow the below steps:

1. Access the Control System Enclosure on the left side of the G-MAX Wagon, under the stainless-steel cover. The six Philips head fasteners require a quarter turn to release.




2. Locate the group of four dip switches on the Load Cell charging circuit board:



3. The Standby Time is the accumulated value of all Dip Switches in the 'Up' position – to a maximum of 1 hour 5 minutes. The Factory setting is 20 minutes.

Updating software version

1. Tap Settings Icon



2. Tap Maintenance Menu Icon




3. Tap "System" Button



4. Insert USB with latest software into screen and press "update" button



5. Press "Begin Update" to begin. When the update reaches 100% the screen will reboot. This reboot will take longer than usual and will cause a blank green screen. Once the reboot is complete, ensure screen stays of for a few minutes.




Exporting Settings to USB

If monitor layouts and settings are customized and changed from factory defaults, they should be backed up on the supplied USB.

1. Turn on screen and insert USB to export settings onto.

2. Tap Settings Icon



3. Tap Maintenance Menu Icon




4. Tap "System" Button




5. Tap "Reset" Button



6. Scroll Down and Tap
"Export Settings to USB"



7. Tap "Ok"




This process should be done as often as settings and layouts are customized.

Importing Settings from USB

1. Turn on screen and insert USB with appropriate .bin file.

2. Tap Settings Icon



3. Tap Maintenance Menu Icon




4. Tap "System" Button



5. Tap "Reset" Button



6. Tap Import Settings from USB



7. Tap "Ok"




8. Run machine to check upload of settings was successful.

Troubleshoot - Enclosure Circuit Boards Identification

The Control System Enclosure is fitted on the front left of the wagon, under the stainless-steel cover. The enclosure lid is held on with six Philips head fasteners, which require a quarter turn to release.

Which Electronic control Option determines which components are fitted.



Main base circuit board – Fitted to all wagons with any electronic control Option

UniPOD Computer – Fitted whenever floor control is Optioned


Load cell board AND Buck Boost board – Both used when scales are fitted

WIFI chip – Fitted to Load cell board gives Wireless Scales Display


Troubleshoot - LED Status Lights

Each circuit board is fitted with LED lights to assist in machine function diagnostics. See diagrams below:

Main Base circuit board and Buck Boost board:




Load cell board



Phone Scales WIFI chip - **OBSOLETE**

- This chip is replaced with the combined Phone/WIFI Scales chip and load cell circuit board on machines built from June 2026.
- Fitted in place of WIFI chip when Phone scales display is Optioned



Troubleshoot - Diagnostic Notes

The tractor should be Turned Off for safety. Start the tractor only when required to test electronic control of a hydraulic function.

Follow all necessary safety precautions.

Ensure the Electronic control system is turned on. The monitor in the cab will power up. If phone scales only is optioned, ensure the tractor loom LED is lit up to indicate 'On.'

Ensure the Tractor loom is plugged in to the Implement loom and the latch lever is clicked in place.

Remove the Electronic enclosure lid and observe which LED's are illuminated.

D1 - Battery LED – This LED remains on at all times, whether the wagon is connected to the tractor or not. If this LED is not On, the battery may be disconnected, discharged, or the fuse blown. If the LED is glowing faintly, the battery may be discharged. This can cause the system to not operate in Standby mode.

D2 - +12V – This LED is On when there is power connected coming from the Tractor AND the Tractor loom switch is On. If not on, check the plug and wiring to Tractor.

NOTE: In order for the Tractor power to be connected to the circuit board, the switching wires must be connected to 'CAN from tractor +12V / GND' terminals.

D3 – Operator LED – This LED operates in conjunction with the LED in the push button. When On, the system is operating on tractor power. When Flashing it is running on wagon battery power. When Off, the system is off. Either press the button or connect tractor plug (ensuring tractor loom is switched On) to turn On the system. If the LED on the circuit board is operating, but the button is not, check the button and its' wiring.

D4 – Load Cell Power – This indicates when power is available on the board for the load cell board. It is turned On whenever the system is On.

D5 – Floor Control – This indicates when power is being sent to the main wagon floor control valve. It is illuminated when the wagon is running. If the wagon floor does not move when the LED is On (and tractor hydraulics are engaged), check the following items:

- Set feed mode to 'Standard.' Increase feed percentage on the touchscreen – too low and the floor won't move.

- Wind manual override knob of floor control in. If wagon floor starts to move, the wiring or coil on the floor control cartridge on the hydraulic block may be faulty. If the wagon still does not start, go to hydraulic troubleshoot guide.

D6 - Elevator Control - This indicates when power is being sent to the elevator On/Off control valve. It is illuminated when the wagon is running. If the elevator does not move when the LED is On (and tractor hydraulics are engaged), check the following items:

- Manually override the elevator control by turning the knob anti clockwise until it clicks. If the elevator starts, the wiring or coil on the elevator control cartridge on the hydraulic block may be faulty. If the elevator still does not start, go to hydraulic troubleshoot guide.

Charge LED – On when system is charging the battery. Note the system senses when a battery is connected and begins charging. If Off when power is connected, the wiring to the battery, fuse or the battery itself may be faulty.

Status LED – On when power is coming in from Tractor, Flashing when battery power is being used. See D3 – Operator LED.

Load Cell LED – Slow Flashing when CANBus is connected (when tractor is plugged in), Fast flashing when no CANBus is connected (running on wagon battery). Off means no power is getting to load cell board. Check wiring connections between load cell board and main base circuit board.

WIFI chip LED's – Red – Power On AND Green fast flashing – WIFI Active. The WIFI signal should be discoverable by the touchscreen monitor. Ensure the aerial is intact and fixed in place inside the enclosure.

- **This part has been superseded by the Combined chip below.**

Phone Scales WIFI chip LED - Blue flashing means WiFi Active. The WIFI signal should be discoverable by any device capable of receiving WIFI. Note the phone scales WIFI chip does not have an aerial.

- **This part has been superseded by the Combined chip below.**

Combined Phone Scales/WIFI chip LED's - Red – Power On. Blue fast flashing – WIFI Active. The WIFI signal should be discoverable by the touchscreen monitor **AND** by any device capable of receiving WIFI. Ensure the aerial is intact and fixed in place inside the enclosure.

- **Note the Combined chip cannot be fitted into earlier loadcell circuit boards. Likewise, the loadcell circuit board to suit this Combined chip cannot be used with earlier chips.**

Troubleshoot – Symptom Table

Symptom	Possible Fault	Remedy
Red running light, Run/Hold does not work	Wagon plug not connected to tractor	Plug in wagon
Floor runs flat out in 'Run' mode and will not stop	Plugs may be incorrectly connected to hydraulic coils on valve block	Set feed rate to 5% and press 'Run.' Engage tractor hydraulics. If Elevator does not operate, swap coil plugs at hydraulic block
Wagon enclosure turns off when disconnected from tractor	- Battery flat - Standby time set to zero minutes	- Charge or replace battery - See 'Adjust Standby time' section
Wagon enclosure turns off when disconnected from tractor, even though Battery LED is On	Battery is discharged	Charge or replace battery
'Charge' LED does not turn on when tractor is connected, even though 'Battery' LED is On	A significantly discharged battery may not accept charge	Replace battery
No power to wagon enclosure	- Tractor loom relay faulty - Plug connections faulty	- Replace relay - Dismantle and clean plug connections

Troubleshoot - Loom Plug Wiring

- Notes: - Wires are connected based on numbered positions on both plugs.
- The numbers can be found on the 'back' side of the plug once disassembled, where the wires actually fit in to the screw blocks.
 - A sticker is fitted where the wires fit in showing the wire number and colour.
 - When the sticker is missing or unreadable the numbers can be found moulded into the plug, sometimes under the sticker.

Tractor Loom Plug		Implement Loom Plug	
			
Wire Colour	Pin	Wire Colour	Function
RED	1	RED	+12V Power from tractor
GREEN	2	BLACK	GND CAN from tractor
-	3	-	-
BLACK	4	BROWN	GND Power from tractor
ORANGE	5	WHITE	+12V CAN from tractor
YELLOW	6	WHITE/GREEN	CAN-H
BLUE	7	WHITE/BROWN	CAN-L

Technical - Hydraulic System Troubleshoot

When using the guide, it has been assumed that the tractor has been checked to provide an oil flow rate of between 30 and 60 litres per minute at full working pressure, usually 2200psi (150 bar) or greater. If these conditions are not satisfied, the forage wagon will perform poorly or not at all.

Please refer to the valve layout diagram on the next page to identify the location of the various valves discussed in the guide.


Notes:

- To allow for lower flow tractors (30l/min and below), cartridge #4c can be changed with other types of valve cartridges to change the floor and elevator motor circuit from a parallel to a series circuit to reduce the oil flow requirement. Please note that this arrangement will cause the machine to run with acceptable speed but reduced power compared to the parallel circuit.
- Cartridge #4c (as fitted as standard) is a check valve (CXDA) for a permanent series connection between the floor and elevator motors. By replacing this with a cavity blank (XFOA) permanent parallel connection is achieved.
- By replacing cartridge #4c with a free flow reverse needle valve (NCCB), it is possible to convert the circuit between series and parallel in the field by winding fully in for series or fully out for parallel.
- Changing cartridge #4c from CXDA to SCCB (set @ 1700psi) will provide pressure relief when the floor is reversed. When relief pressure is reached, the conveyor belt will begin to operate in reverse.
- Machines that develop or operate with a jerking or shuddering action can be rectified by fitting a non-standard inline valve (SCCB 154Z P8) with relevant fittings between the port marked 'ELEV PRES' and the elevator motor. This preloads the hydraulic circuit and smooths the operation.
- If Elevator power seems low, check 4(d) is the correct CXDA cartridge. Early manual control blocks were fitted with XFOA blanks which must be changed to CXDA when electronic control is fitted.


Note: This procedure was written specifically for Giltrap machines fitted with the 4045A valve assembly (stamped on the block itself).

If you have an older Giltrap model, contact Giltrap Engineering for advice or a different trouble shooting procedure.

4045A Valve Layout – Electronic Control



4045A Valve Layout – Manual Control



Giltrap Wagon Check Sheet

New wagons are factory tested with a total operating pressure of about 1000psi.

Pressures higher than this are usually caused by a tight or off-centre conveyer belt, tight elevator and/or floor chains, or bearings that are seized or need greasing.

A conveyer extension belt (if fitted) will add 200-300psi to the operating pressure.

Tractors that are supplying greater than 60 litres/min may also cause additional back pressure and should be throttled back to the recommended flow parameters.

Tips:


To isolate mechanical from hydraulic faults, motors can be mechanically uncoupled from the shaft they are powering and run with no load. If the high pressure reading drops dramatically with no load attached, it is generally safe to assume that the fault is mechanical (i.e. bent shaft, tight chains, collapsed bearing etc).


If a problem persists, identify the operating symptoms and use the trouble shooting flow chart to isolate and rectify the problem.

Contact your Giltrap dealer about our hydraulic block service-exchange programme

FOLLOW 4045A with Electronic Control Trouble shooting chart

BEFORE 4045A Trouble shooting chart






Parts Section

ELECTRONIC CONTROL SYSTEM COMPONENTS	56
BOTTOM CHASSIS	58
RIMA JACK	59
FRONT PANELS – JUNE 2025 ON.....	60
FRONT PANELS – PRE- JUNE 2025 – BOLT-ON COMBING RAIL	62
FLOOR CHAIN DRIVE ASSEMBLY – JUNE 2025 ON	64
FLOOR CHAIN DRIVE ASSEMBLY – PRE-JUNE 2025	65
FLOOR CHAIN IDLER ASSEMBLY	66
FLOOR BAR SETUP	67
BELT CROSS CONVEYOR.....	68
CHAIN CROSS CONVEYOR	69
HEAVY DUTY CROSS CONVEYOR EXTENSION – CONVEYOR	70
HEAVY DUTY CROSS CONVEYOR EXTENSION – MOUNTS	71
ELEVATOR – JUNE 2025 ON.....	72
ELEVATOR – TOP ASSEMBLY – PRE-JUNE 2025	74
REAR GATE.....	75
CONTROL ENCLOSURE COMPONENTS	76
MUDGUARDS	77
AXLE ASSEMBLY	78
HUB ASSEMBLY – ADR	79


Electronic Control System Components



Electronic Option A - Wireless scales with manual floor control
Electronic Option B - Wireless electronic rate control without scales
Electronic Option C - Wireless scales and full automatic feed rate control
Electronic Option D - Phone based wireless scales with manual floor control

Item	Part Number	Description	Option A qty	Option B qty	Option C qty	Option D qty
1	7105Pro	7" Feed Wagon WIFI display	1	1	1	-
2	11660-LEV	Tractor Loom - Lever lock type	1	1	1	-
	15505	Tractor Loom - Phone Scales Display only	-	-	-	1
3	11647-LEV	Implement Loom, SmartAg - Fert Spreader and G-MAX	1	1	1	1
4	TCS-BATTERY2	Battery SLA 7.2Ah c/w F2 Terminals	1	-	1	1
5	A-Unipod-VRC-2	2 bin Unipod @ 5 buy price	-	1	1	-
	A-WIFI-C	WIFI Chip Module - Wagon Controller with antenna	1	-	1	-
6	No Longer Available - see item 9					
	A-5009-W-GIL	WIFI Chip Module- Phone	-	-	-	1
7	No Longer Available - see item 9					
8	K-5100-BB-01	Base Box	1	1	1	1
		Load cell addition – comes with Combined Phone Scales/WIFI chip	1	-	1	1
9	K-5100-LC-01					
10	#ES-2C	Dual Core Wire for Coil	-	Measure to Order	Measure to Order	-
11	11695	DIN Coil Plug	-	2	2	
12	ES-WLY00003P	Load Cell, PT 5,000Kg - RF Wagons & Fert Spreaders	G-MAX9-11: 4 off G-MAX13+: 6 off	-	G-MAX9-11: 4 off G-MAX13+: 6 off	G-MAX9-11: 4 off G-MAX13+: 6 off
13		Standby Button (supplied with Base Box)	1	-	1	1
14	11652	Proximity Sensor	-	-	1	-
15	11657	Sensor Cable - Straight Plug - 10m	-	-	1	-
		Battery Isolator loom (including switch)				
16	15537	Note: fitted from mid-2025	1	-	1	1



Bottom Chassis



Item	Part Number	Description	Qty GMAX9	Qty GMAX11	Qty GMAX13	Qty GMAX16	Qty GMAX21
1	14856	Bumper	1	1	1	1	1
2	15061	Hose Holder	1	1	1	1	1
3	14937	Swivel Tow Eye	1	1	-	-	-
-	13918	Swivel Tow Eye	-	-	1	1	1
4	14987	Quick Hitch foot (optional)	1	1	1	1	1
5	14902	Hydraulic Jack (optional)	1	1	-	-	-
-	14876	Hydraulic Jack (optional)	-	-	1	1	1
6	14099	CC holder	2	2	2	2	2
7	301-4020	Jack	1	1	1	1	1
8	ES- WLY00003P	PT 5000 Load cell (optional)	4	4	6	6	6
9	700-0200	Cell float bolt	4	4	6	6	6
10	A-SW20/40	Spherical Washer	4	4	6	6	6


Rima Jack

RIMA Parking Jack



21	90064755	1
20	90076770	1
19	90068800	1
18	90070956	1
17	90068720	1
16	90071940	1
15	900411324	1
14	900416341	1
13	979303981	1
12	90064766	4
11	90079350	4
10	90039930	2
9	90049035	1
8	90033262	1
7	90033253	1
6	90069014	2
5	90041090	1
4	90034200	1
3	90057712	1
2	940655403	1
1	940275933	1
Item:	Code:	Q.ty:


Front Panels – June 2025 on



Item	Part Number	Description	Qty GM9	Qty GM11	Qty GM13	Qty GM16	Qty GM21
1	14739	Front lower panel	1	1	1	1	1
2	14843	Front upper panel	1	1	1	1	-
-	15359	Front upper panel	-	-	-	-	1
3	14925	Gap filler	1	1	1	1	1
4	14894	Forward lower right panel	1	1	1	1	1
5	14905	Forward right upper panel	1	1	1	1	-
-	15358	Forward right upper panel	-	-	-	-	1
6	SCOIL1.2/SSS	Side panel	2	-	-	-	-
-	SCOIL1.2/SSS	Side panel	-	2	-	-	-
-	SCOIL1.2/SSS	Side panel	-	-	2	-	-
-	SCOIL1.2/SSS	Side panel	-	-	-	2	-
-	SCOIL1.2/SSS	Side panel	-	-	-	-	2
7	15455	Front Right Upright	1	-	-	-	-
-	15428	Front Right Upright	-	1	1	1	-
-	15438	Front Right Upright	-	-	-	-	1
8	15454	Side Upright	4	-	-	-	-
-	15427	Side Upright	-	4	6	8	-
-	15437	Side Upright	-	-	-	-	10
9	15460	Combing Rail (Right hand)	1	-	-	-	-
-	15443	Combing Rail (Right hand)	-	1	-	-	-
-	15433	Combing Rail (Right hand)	-	-	1	-	-
-	15448	Combing Rail (Right hand)	-	-	-	1	-

Item	Part Number	Description	Qty GM9	Qty GM11	Qty GM13	Qty GM16	Qty GM21
-	15442	Combing Rail (Right hand)	-	-	-	-	1
10	15457	Right Rear Upright	1	-	-	-	-
-	15426	Right Rear Upright	-	1	1	1	-
-	15439	Right Rear Upright	-	-	-	-	1
11	699-1002	Gate stay	1	1	1	1	1
12	15436	Gate brace beam	1	1	1	1	1
13	15198	Floor Outer RH	1	1	-	-	-
-	15182	Floor Outer RH	-	-	1	-	-
-	14854	Floor Outer RH	-	-	-	1	-
-	15370	Floor Outer RH	-	-	-	-	1
14	15199	Floor Centre	1	1	-	-	-
-	15183	Floor Centre	-	-	1	-	-
-	14855	Floor Centre	-	-	-	1	-
-	15371	Floor Centre	-	-	-	-	1
15	15198	Floor Outer LH	1	1	-	-	-
-	15182	Floor Outer LH	-	-	1	-	-
-	14854	Floor Outer LH	-	-	-	1	-
-	15370	Floor Outer LH	-	-	-	-	1
16	15460-LH	Combing Rail (Left hand)	1	-	-	-	-
-	15443-LH	Combing Rail (Left hand)	-	1	-	-	-
-	15433-LH	Combing Rail (Left hand)	-	-	1	-	-
-	15448-LH	Combing Rail (Left hand)	-	-	-	1	-
-	15442-LH	Combing Rail (Left hand)	-	-	-	-	1
17	15458	Left Rear Upright	1	-	-	-	-
-	15425	Left Rear Upright	-	1	1	1	-
-	15441	Left Rear Upright	-	-	-	-	1
18	15456	Front Left Upright	1	-	-	-	-
-	15424	Front Left Upright	-	1	1	1	-
-	15440	Front Left Upright	-	-	-	-	1
19	15435	Ladder	1	1	1	1	-
-	15378	Ladder	-	-	-	-	1
20	14842	Left side panel	1	1	1	1	1
21	15469	Gearbox cover	1	1	1	1	1
22	14835	Forward upper left panel	1	1	1	1	-
-	15357	Forward upper left panel	-	-	-	-	1
23	14063- RH	Gate Latch (Right hand)	1	1	1	1	1
24	14064	Gate Latch bush	2	2	2	2	2
25	14063-LH	Gate Latch (Left hand)	1	1	1	1	1

Front Panels – Pre- June 2025 – Bolt-on Combing Rail




- This information relates to machines with bolt-on combing rails (items 9 & 16). If the machine has combing rails welded to the uprights, refer to previous view/table.

- If the machine has bolted on Upright Extension brackets, please contact Giltrap Engineering for Part Number information.

Item	Part Number	Description	Qty GM9	Qty GM11	Qty GM13	Qty GM16
1	14739	Front lower panel	1	1	1	1
2	14843	Front upper panel	1	1	1	1
3	14925	Gap filler	1	1	1	1
4	14894	Forward lower right panel	1	1	1	1
5	14905	Forward right upper panel	1	1	1	1
6	SCOIL1.2/SSS	Side panel – length as req.	2	-	-	-
-	SCOIL1.2/SSS	Side panel – length as req.	-	2	-	-
-	SCOIL1.2/SSS	Side panel – length as req.	-	-	2	-
-	SCOIL1.2/SSS	Side panel – length as req.	-	-	-	2
7	15327	Front Right Upright	1	-	-	-
-	14837	Front Right Upright	-	1	1	1
8	15320	Side Upright	4	-	-	-
-	14852	Side Upright	-	4	6	8


Item	Part Number	Description	Qty GM9	Qty GM11	Qty GM13	Qty GM16
9	15321-RH	Combing Rail (Right hand)	1	-	-	-
-	14895-RH	Combing Rail (Right hand)	-	1	-	-
-	15179-RH	Combing Rail (Right hand)	-	-	1	-
-	14838-RH	Combing Rail (Right hand)	-	-	-	1
10	15319	Right Rear Upright	1	-	-	-
-	14738	Right Rear Upright	-	1	1	1
11	699-1002	Gate stay	1	1	1	1
12	14850	Gate brace beam	1	1	1	1
13	15198	Floor Outer RH	1	1	-	-
-	15182	Floor Outer RH	-	-	1	-
-	14854	Floor Outer RH	-	-	-	1
14	15199	Floor Centre	1	1	-	-
-	15183	Floor Centre	-	-	1	-
-	14855	Floor Centre	-	-	-	1
15	15198	Floor Outer LH	1	1	-	-
-	15182	Floor Outer LH	-	-	1	-
-	14854	Floor Outer LH	-	-	-	1
16	15321-LH	Combing Rail (Left hand)	1	-	-	-
-	14895-LH	Combing Rail (Left hand)	-	1	-	-
-	15179-LH	Combing Rail (Left hand)	-	-	1	-
-	14838-LH	Combing Rail (Left hand)	-	-	-	1
17	15329	Left Rear Upright	1	-	-	-
-	14738-LH	Left Rear Upright	-	1	1	1
18	15318	Front Left Upright	1	-	-	-
-	14837-LH	Front Left Upright	-	1	1	1
19	14874	Ladder	1	1	1	1
20	14842	Left side panel	1	1	1	1
21	14853	Gearbox cover	1	1	1	1
22	14835	Forward upper left panel	1	1	1	1
23	14063- RH	Gate Latch (Right hand)	1	1	1	1
24	14064	Gate Latch bush	2	2	2	2
25	14063-LH	Gate Latch (Left hand)	1	1	1	1

Floor Chain Drive Assembly – June 2025 on




Item	Part Number	Description	Qty GM9	Qty GM11,13	Qty GM16	Qty GM21
1	14960-RH	Outer Guard (Right hand)	1	1	1	1
2	14834	Centre Guard	1	1	1	1
3	14960-LH	Outer Guard (Left hand)	1	1	1	1
4	615-2023	Deadeye bearing 45mm	2	-	-	-
-	615-2044	Deadeye bearing 50mm	-	2	2	-
-	615-2055	Deadeye bearing 55mm	-	-	-	2
5	615-1118	Deadeye bearing Two leg 45mm	1	-	-	-
-	615-1127	Deadeye bearing Two leg 50mm	-	1	1	-
-	615-1130	Deadeye bearing Two leg 55mm	-	-	-	1
6	GBRT300-45-PTG	Gearbox Berma RT300-45 Painted Grey	1	1	1	-
7	HYM130-PTG	Hydraulic Motor TEO130cc Painted Grey	1	1	-	-
-	HYM195-PT	Hydraulic Motor TEO195cc Painted	-	-	1	1
8	14659	Retainer washer	1	1	1	-
9	14851	Gearbox torque arm	1	1	1	-
10	14229	Mount brace	-	-	-	1
11	GBRT400-55-PT	Gearbox Berma RT400-55 Painted	-	-	-	1
12	14948	5T 45mm Drive Sprocket	2	-	-	-
-	14962	5T 50mm Drive Sprocket	-	2	2	-
-	14118	5T 55mm Drive Sprocket	-	-	-	2
13	15478	Drive shaft	1	-	-	-
-	15476	Drive shaft	-	1	1	-
-	15369	Drive shaft	-	-	-	1

Floor Chain Drive Assembly – Pre-June 2025




Item	Part Number	Description	Qty GM9	Qty GM11,13,16
1	14960-RH	Outer Guard (Right hand)	1	1
2	14834	Centre Guard	1	1
3	14960-LH	Outer Guard (Left hand)	1	1
4	14948	5T 45mm Drive Sprocket	2	-
-	14962	5T 50mm Drive Sprocket	-	2
5	615-2023	Deadeye bearing 45mm	2	-
-	615-2044	Deadeye bearing 50mm	-	2
6	615-1118	Deadeye bearing Two leg 45mm	1	-
-	615-1127	Deadeye bearing Two leg 50mm	-	1
7	14623	Gearbox coupling 45mm female	1	-
-	135-4128	Gearbox coupling 50mm female	-	1
8	135-4142	Gearbox coupling male	1	1
9	GBRT300-45-PTG	Gearbox Berma RT300-45 Painted Grey	1	1
10	HYM130-PTG	Hydraulic Motor TEO130cc Painted Grey	1	1
11	14659	Retainer washer	1	1
12	14851	Gearbox torque arm	1	1
13	14891	Drive shaft 45mm	1	-
-	14844	Drive shaft 50mm	-	1

Floor Chain Idler Assembly



Item	Part Number	Description	Qty GM9	Qty GM11-21
1	14847-RH	Floor Retainer Outer (Right hand)	1	1
2	14848	Outer end cap	2	2
3	14814	Puller	1	1
4	14946	Adjuster	2	-
-	14034	Adjuster	-	2
5	14036	Spacer	2	2
6	210-0012	6T Idler	2	-
-	12182	6T Idler – Large chain	-	2
7	597-1036	Chain ring	4	-
-	14955	Large chain ring	-	4
8	597-1029-1	6 th Idler Axle assy	2	2
9	14042	Tensioner rod	2	2
10	NN24	Nylock nut M24	2	2
11	14849	Centre end cap	1	1
12	14846	Floor retainer centre	1	1
14	14847-LH	Floor Retainer Outer (Left hand)	1	1
15	14947	Sprocket Adjuster assembly (items 4-8)	2	-
-	14035	Sprocket Adjuster assembly, Large chain (items 4-8)	-	2


Floor Bar setup



NOTE: ensure correct floor slat for Serial Number is specified when ordering parts.
Floor slat P/N 15838 Must Not be fitted to earlier machines.


Item	Part Number	Description	Qty GM9	Qty GM11	Qty GM13	Qty GM16	Qty GM21
1	14949	Floor Slat bolt-on – GMAX 10mm chain	12	-	-	-	-
-	14629 – used up to S/N: AONL19488	Floor Slat bolt-on – GMAX 13mm chain	-	11	14	17	20
-	15838 – used from S/N: AONL19489	Floor Slat bolt-on – GMAX 13mm chain. Has notches in ends for identification	-	11	14	17	20
2	N12	Nut M12	24	-	-	-	-
-	NN16	Nylock nut M16	-	22	28	34	40
3	605-3001-1	Floor slat bush	24	-	-	-	-
-	14628	Floor bar spacer M16	-	22	28	34	40
4	CH10HTLL	Chain 10mm High Tensile	As req	-	-	-	-
-	CH42520	13mm Chain	-	2x 6.92m	2x 8.91m	2x 10.9m	2x 13.4m
5	BCH12X60	Bolt, Coach M12x60 Galv	24	-	-	-	-
-	BCH16x85	Coach bolt 16 x 85 - GMAX	-	22	28	34	40
6	WASG12	Spring washer M12	24	-	-	-	-
-	WA16	Flat washer M16	-	22	28	34	40
7	230-1007	10mm chain joiner link	2	-	-	-	-
-	230-1307	13mm chain joiner link	-	2	2	2	2

Belt Cross Conveyor




Item	Part Number	Description	Quantity
-	13920	Cross Conveyor Bed 1200 Incl Belt – GMAX	-
-	501-9120	CC Belt w Slats 4.500x1200	1
1	554-1136	Motor Coupling - Male	1
2	554-1143	Motor Coupling - Female	1
3	13947	P mount	1
4	HYM65-PT	Hydraulic Motor 65cc Painted Giltrap Red	1
5	13946	Guard	1
6	14549	Motor Retainer	1
7	13928	Stay Mount	1
8	13925	Retainer Strip	2
9	501-9521	Belt Edge cover	2
10	13922	Tensioner	1
11	14343	Idler Roller only, 1200mm (bearings NOT incl.)	1
-	14344	Idler Roller Assembly (includes #11, 12, 13)	1
12	14297	Idler shaft	1
13	BRGYAR206	Idler Roller Bearing Insert 30mm	2
14	15412	Washer	4
15	13927	Scraper	2
16	13924	Adjuster	2
17	13923	Puller	2
18	14928	CC locator	1
19	13921	Frame	1
20	BRGYET205	BRG Insert m/coil 25mm	2
21	HSG-CCRDS	Self-Aligning Bearing Housing	2
22	501-9514-1200	CC-RF Roller Drive 1200mm	1
-	CCRAD-RF1200	Drive Roller Assembly (Includes #20, 21 & 22)	1

Chain Cross Conveyor



Item	Part Number	Description	Quantity
-	13944	Chain Bed Assembly 1200 - GMAX	-
1	554-1136	Motor Coupling - Male	1
2	554-1143	Motor Coupling - Female	1
3	13947	P mount	1
4	HYM80-PT	Hydraulic Motor 80cc Brevini, Painted	1
5	13946	Guard	1
6	14549	Motor Retainer	1
7	501-8022-1	Slat / Bar for RF Chain Bed 1200 mm	As req.
-	501-8022	Chain & Slat set – RF Chain Bed 1200 mm	1
8	13928	Stay Mount	1
9	CH6000-2	Chain, 2" Pitch, 6000lb Hollow Pin, length to suit	2
10	13938	Rear Cover	1
11	10139	Idler shaft	1
12	15335	Welded housing	1
-	13937	Chain Idler End assembly (includes #11,12,14,15)	1
13	13939	Mount tab	2
14	BRG6307	Bearing	4
15	211-0007-1	Sprocket	4
16	13922	Tensioner	1
17	13924	Adjuster	2
18	13923	Puller	2
19	13921	Frame	1
20	15335	Welded housing	1
-	13935	Chain Drive End assembly (includes #14,15,20,21)	1
21	10138	Drive shaft	1
22	13940	Plastic floor	1
23	10145	Floor retainer	1


Heavy Duty Cross Conveyor Extension – Conveyor



Note: 1m version shown


Item	Part Number	Description	Quantity 1m Unit	Quantity 2m Unit
1	BRGYET205	Bearing Insert with collar, 25mm	4	4
2	HSGTU505	Bearing housing, Take Up, 25mm	4	4
3	501-9518-1200	Complete Idler Roller assy, HD 1200mm	1	1
4	501-9102	CC Belt w Slats 2250x1200	1	-
-	501-9109	CC Belt w Slats 4250x1200	-	1
5	13925	Retainer strip	2	2
6	15239	Complete Drive Roller assy, HD 1200mm	1	2
7	501-9521	Rubber Insert strip	2	2
8	14549	Motor Retainer	1	1
9	554-1136	Motor Coupling - Male	1	1
10	554-1143	Motor Coupling - Female	1	1
11	HYM40-PT	Hydraulic Motor Generic 40cc – Painted	1	1
12	590-0177-1	CC motor mount	1	1
13	15193	1200 CCE 1m Bed Weldment	1	-
-	15910	1200 CCE 2m Bed Weldment	-	1
14	596-1001	Adjuster screw	4	4

Heavy Duty Cross Conveyor Extension – Mounts



Item	Part Number	Description	Quantity
1	15211	Bumper modified	1
2	15210	Front Upstand	1
3	15209	Front mount	1
4	RAM2x1x12	Ram 2" bore x 12" stroke	1
5	15235	Pin	1
6	15506	Mount spacer (used as necessary)	As req
7	15213	Rear mount	1
8	15214	Rear Upstand	1


Elevator – June 2025 on



- See table next page


Item	Part Number	Description	Qty GM9	Qty GM11	Qty GM13	Qty GM16	Qty GM21
EA	15463	Elevator Assembly	1	-	-	-	-
-	15462	Elevator Assembly	-	1	1	1	-
-	15464	Elevator Assembly	-	-	-	-	1
TA	15465	Elevator Top Assembly	1	-	-	-	-
-	15466	Elevator Top Assembly	-	1	1	1	-
-	15466-V	Elevator Top Assembly	-	-	-	-	1
1	15467	Elevator shaft	1	1	1	1	1
2	14826	Guard	1	1	1	1	1
3	210-0004	Drive Sprocket 5T	2	-	-	-	-
	- add 14956	For G-MAX9 only	2	-	-	-	-
-	12180	Drive Sprocket 5T	-	2	2	2	2
4	14957	Labyrinth	2	-	-	-	-
-	14825	Labyrinth	-	2	2	2	2
5	615-1999-LH	Cast dead eye	1	1	1	1	-
-	11385	Bushed Bearing	-	-	-	-	1
6	615-1999-RH	Cast dead eye	1	1	1	1	-
-	11386	Bushed Bearing	-	-	-	-	1
7	11384	Bush only	-	-	-	-	2
8	14823	Top frame	1	1	1	1	1
9	14816	Lower frame	1	1	1	1	-
-	15355	Lower frame	-	-	-	-	1
10	597-1029-1	Idler axle assy	2	2	2	2	2
11	15461	Pipe spacer	2	2	2	2	2
12	210-0012	Idler 6 tooth	2	-	-	-	-
-	12182	Idler 6 tooth – Large chain	-	2	2	2	2
13	14831	Plastic pad	2	2	2	2	-
-	15356	Plastic pad	-	-	-	-	2
14	14824	Adjuster	2	2	2	2	2
15	14819	Disc	1	1	1	1	1
16	15468	Gearbox Mount	1	1	1	1	1
17	HYM80- PARKER-PT	Hydraulic motor 80cc	1	1	1	1	1
18	GBRT160-PT	Gearbox RT160 Painted	1	1	1	1	1
19	230-1007	10mm chain joiner link	2	-	-	-	-
-	230-1307	13mm chain joiner link	-	2	2	2	2
20	232-0021	10mm Elevator Chain assy	2	-	-	-	-
-	232-0069	13mm Chain & tag assy	-	2	2	2	-
-	232-0070	13mm Chain & tag assy 21	-	-	-	-	2
21	595-3010	Forged Elevator Bar Tag & Bolt Assy	10	-	-	-	-
22	501-0071	Elevator Spiked bar - RH	5	5	5	5	6
-	501-0072	Elevator Spiked bar - LH	5	5	5	5	5

Elevator – Top Assembly – pre-June 2025




Item	Part Number	Description	Qty GM9	Qty GM11-GM16
-	15331	Elevator Top Assembly	1	-
-	15235	Elevator Top Assembly	-	1
1	14826	Guard	1	1
2	14818	Elevator Shaft	1	1
3	615-1999-RH	Cast dead eye	1	1
4	615-1999-LH	Cast dead eye	1	1
5	210-0004	Drive Sprocket 5T	2	-
-	- add 14956	For G-MAX9 only	2	-
-	12180	Drive Sprocket 5T	-	2
6	14957	Labyrinth	2	-
-	14825	Labyrinth	-	2
7	B12x45	Bolt	4	4
8	14830	Coupling lock washer	8	8
9	NN12	Nylock nut M12	4	4
10	14823	Top frame	1	1
11	14819	Disc	1	1
12	HYM80-PARKER-PT	Hydraulic motor 80cc	1	1
13	14829	Gearbox Mount	1	1
14	GBRT160-PT	Gearbox RT160 Painted	1	1
15	14073	Male coupling	1	1
16	14072	Female coupling	1	1
17	14827	Coupling cover	1	1
18	14853	Gearbox cover	1	1
19	14845	Elevator Gapfill cover	1	1

Rear Gate




Item	Part Number	Description	Quantity
1A	LightLed-LH	LED Tail light Left hand	1
1B	LightLed-RH	LED Tail light Right hand	1
2	14861	Rear Gate complete G-MAX 9-16	1
		Rear Gate complete G-MAX 21	1
3	PFCAP25G	Cap, galvanised	1
4	B10x65	Bolt, M10x65	1
5	NN10	Nut, Nyloc M10	1
6	SGC100x24	Spring, Compression 100 x 22OD x 5	1
7	BRGUC1"	Ball Bearing, 1"	1
8	14865	Retainer	1
9	14866	Seal Strip	1
10	14862	Latch	1

Control Enclosure Components



Item	Part Number	Description	Quantity
1	14873-1	Filler 1	1
2	14873-2	Filler 2	1
3	14869	Forward cover mount	1
4	-	Electronic Control Enclosure (optional)	As req.
5	14096	Enclosure mount	1
6	14870	Top folding	1
7	TCS-Battery2	Battery (optional)	As req.
8	COMAC-5704	Latch striker plate	2
9	14867	Rear cover mount	1
10	15065	Hyd cover	1
11	14871	Lower side mount	1
12	14868	Hydraulic block mount	1
13	HYHCV-4045-2	Hydraulic valve block – GMAX (manual)	As req.
-	HYHCV-4045A	Hydraulic valve block – (Electronic) GMAX	As req.
14	14872	Stainless steel cover	1
15	COMAC-3056	Grab handle	1
16	COMAC-5702	Hold down latch	2
17	HYHCV166H RDDA G-MAX	Floor Reverse Pressure Relief valve. One fitted to G-MAX21 and up.	As req.

Mudguards




Item	Part Number	Description	Qty GMAX9 Tyre: 11.5/80-15.3	Qty GMAX11 Tyre: 400/60-15.5	Qty GMAX13 Tyre: 400/60-15.5	Qty GMAX13 Tyre: 400/55-22.5	Qty GMAX16 Tyre: 400/55-22.5	Qty GMAX16 Tyre: 500/60-22.5	Qty GMAX21 Tyre: 500/60-22.5
1	14899-LH	Brace Left hand	2	2	2	-	-	-	-
-	15203-LH	Brace Left hand	-	-	-	2	-	-	-
-	14875-LH	Brace Left hand	-	-	-	-	2	-	-
-	15075-LH	Brace Left hand	-	-	-	-	-	2	2
2	14899-RH	Brace Right hand	2	2	2	-	-	-	-
-	15203-RH	Brace Right hand	-	-	-	2	-	-	-
-	14875-RH	Brace Right hand	-	-	-	-	2	-	-
-	15075-RH	Brace Right hand	-	-	-	-	-	2	2
3	14858-RH	Guard End Right hand	2	2	2	2	2	-	-
-	15074-RH	Guard End Right hand	-	-	-	-	-	2	2
4	14858-LH	Guard End Left hand	2	2	2	2	2	-	-
-	15074-LH	Guard End Left hand	-	-	-	-	-	2	2
5	14859	Edge Joiner	4	4	4	4	4	4	4
6	14900	Guard panel	2	2	2	-	-	-	-
-	14857	Guard panel	-	-	-	2	2	-	-
-	15073	Guard panel	-	-	-	-	-	2	2
7	14968	Mud deflector	1	1	1	1	-	-	-

Note: Left side guard shown. Right side guard is mirrored.

Quantities are per complete machine


If your tyre size is not listed, contact the Giltrap Parts Department

Axle Assembly



Item	Part Number	Description	Qty GM9	Qty GM11	Qty GM13	Qty GM16	Qty GM21
1	13524	Cross Beam 1900mm	1	1	1	1	
1	15430	Cross Beam, GMAX21					1
2	15572	975 Hybrid Walking Beam 60mm stub	2				
2	15491	975 Hybrid Walking Beam 70mm Stub		2	2		
2	15641	1250 Hybrid Walking Beam				2	
2	15431	Gull Wing Walking Beam, 1350					2
3							
4	12523	60mm Hub Sleeve	2				
4	13464	70mm Hub Sleeve		2	2		
4	13462	80mm Stub Sleeve				2	
5	HUB2000KG	Complete Stub Axle, ADR 6 stud 60sq	2				
5	HUB3000KG	Complete Stub Axle, ADR 6 stud 70sq		2	2		
5	HUB4250KG	Complete Stub Axle, ADR 8 stud 80sq				2	
6	13109	Axle Shaft - 60mm	2	2	2	2	
6	BEAPHD	Axle Shaft					
7	13110	Axle Bush	4	4	4	4	
7	C28176	Axle Bush	-	-	-	-	4

Hub Assembly – ADR



- See table next page

Item	Giltrap Part #	Description	Quantity			
			60mm	70mm	80mm	90mm
1	HUB2000KG	Complete Stub Axle, ADR 6 stud 60sq	1			
1	HUB3000KG	Complete Stub Axle, ADR 6 stud 70sq		1		
1	HUB4250KG	Complete Stub Axle, ADR 8 stud 80sq			1	
1	HUB5000KG	Complete Stub Axle, ADR 8 stud 90sq				1
2	110-0193	Seal 57x100x10 O/A (80x100x8 nom.)	1			
2	110-0194	Seal 67x120x12 O/A (100x120x10)		1		
2	110-0195	Seal 78x130x10 O/A (108x130x8)			1	
2	110-0196	Seal 82x140x10 O/A (119x140x8)				1
3	BRG30208J2	Taper Roller Bearing, 30208 J2	1			
3	BRG32210J2	Taper Roller Bearing, 32210 J2		1		
3	BRG32212J2	Taper Roller Bearing, 32212 J2			1	
3	BRG32213J2	Taper Roller Bearing, 32213 J2				1
4	BRG30211J2	Taper Roller Bearing, 30211 J2	1			
4	BRG30213J2	Taper Roller Bearing, 30213 J2		1		
4	BRG32215J2	Taper Roller Bearing, 32215 J2			1	
4	BRG32216J2	Taper Roller Bearing, 32216 J2				1
5	110-0945	Wheel Stud, M18x50	6	6	8	
5	110-0950	Wheel Stud, M20x60x1.5				8
6	110-0917	Wheel Nut, M18	6	6	8	
6	110-0919	Wheel Nut, M20x1.5				8
7	-	Hub Only	1	1	1	1
8	GRN8-45	Grease Nipple, M8x1.0 45 deg	1	1	1	1
9	110-1047	Slotted Nut, M39x1.5	1	1		
9	110-1060	Slotted Washer Nut, M48x1.5			1	1
10	-	Retaining Clip (or Split Pin SP5x70)	1			
10	-	Retaining Clip (or Split Pin SP5x70)		1		
10	-	Retaining Clip (or Split Pin SP5x80)			1	
10	-	Retaining Clip (or Split Pin SP5x90)				1
11	110-0799	Grease Cap ADR Pressed Steel -	1			
11	110-0881	Grease Cap ADR Pressed Steel -		1		
11	110-0883	Grease Cap ADR Pressed Steel -			1	
11	110-0884	Grease Cap ADR Pressed Steel -				1



We've assembled a comprehensive dealer network that knows what it takes to keep your Giltrap machinery in peak condition. With a blend of local knowledge and engineering expertise our team is here 24/7, so your business doesn't have to stop.

To find out more about our local dealer network or to discuss your specific needs, contact a member of our team.

NEW ZEALAND (HEAD OFFICE)

TEL +64 7 873 4199

EMAIL info@giltrapag.co.nz

giltrapag.co.nz

AUSTRALIA

TEL +61 3 9369 6548

EMAIL sales@giltrapag.com.au

giltrapag.com.au

To find your local Giltrap and Duncan dealer visit
giltrapag.co.nz/our-dealers